

Polycom VVX Plug-In Guide

It's easy! Simply:

1. Plug into power (if POE is not used)
2. Plug into wall or switch
3. Plug into Ethernet port on computer
4. Insert optional APP-51 headset adapter
5. Insert straight portion of coil cord into groove and plug into handset

